



Tools for the Job



Changing Your Oil

- Typically, 5 quarts of new Quaker State® motor oil
(See owner's manual for recommended oil grade, specification and amount.)
- New Quaker State® oil filter
(Contact the Quaker State Filter Application Hotline at 1-800-526-4250 or online filter catalog at www.quakerstate.com for your vehicle's oil filter application.)
- Vehicle jack and jackstands, or driveway ramps
- Wheel chocks (to reduce rollback)
- Correct oil filter wrench
- Correct size box-end wrench (either metric or standard) for drain-plug removal. If unavailable, use a socket wrench (6-pt). (Quaker State recommends NOT using a crescent [adjustable] wrench, as it can increase likelihood of damage to drain plug.)
- Torque wrench (Most owner's manuals specify a torque spec for drain plug. Consult your owner's manual.)
- An oil catch pan (plastic or metal) that can hold at least 2 gallons of oil
- 1-2 plastic containers (such as gallon milk cartons)
- Funnel
- Safety glasses
- Old rags and/or paper towels
- Rubber gloves (recommended)
- Old clothes you don't mind getting soiled
- About 30-45 minutes of time



▲ Before changing your oil, please refer to your owner's manual for specific instructions and precautions.